

# TOPIT COMPACT

## Assembly instruction

Mounted on drawer sides



**1.** Take the frame out of the packaging.



**2.** Place the frame on the drawer sides.



**3.** Attach the frame on the drawer front using 4 screws.  
2 screws on each side.



**4.** Insert bins, lid and dividers.



**5.** Done!