

# TREND COMPACT

## Assembly instruction

Mounted on drawer sides.



**1.**



**2.** Place the frame on the drawer sides.



**3.** Attach the frame to the drawer front and to the drawer sides.



**4.** 2x2 screws in the front, 3x2 screws on the sides.



**5.** Insert bins and lid.