

SLIM

Assembly instruction

Mounted on drawer sides.



1.



2. Place the frame on the drawer sides.



3. Attach the frame on the drawer front and on the drawer sides.



4. 2x2 screws in the front and 3x2 screws on the sides



5. Insert bins, lid and divider.