

# CUBE COMPACT

## Assembly instruction

Mounted on drawer bottom.



**1.** Unfold the sides of the frame.



**2.** Place the frame in the drawer.



**3.** Attach the frame on the front of the drawer using 2x2 screws. Use the outer holes.



**4.** Attach the frame on the bottom of the drawer using 2x2 screws.



**5.** Insert bins and lid.