

# TREND

## Assembly instruction


Mounted on drawer sides.



- 1.** If you want to use the tape, remove the protective strip. If you use the tape, screws in drawer sides are optional.



- 2.** Place the frame on the drawer sides.



- 3.** Attach the frame to the drawer front and to the drawer sides. 2x2 screws in the front, 3x2 screws on the sides.



- 4.** Insert bins, lid and dividers.